

# *PulsGuide*

by Rigel Systems

**Easier Guiding Equals  
Better Astrophotographs**

***Featuring***  
**Compact & Self Contained  
Long Battery Life**

**ON-OFF/Brightness Adjustment:**  
**(single knob on end)** Rotate the knob clockwise to increase, Counterclockwise to click off.

**Timing Adjustment: (paired knobs)** Rotate the knob nearest eyepiece counterclockwise to increase the on time. Rotate the knob farthest from eyepiece counterclockwise to increase the off time. For continuous operation rotate the knob nearest the eyepiece fully counterclockwise and the knob furthest from the eyepiece fully clockwise.

**Battery Installation:** Uses one 1/3N Duracel XL DL1/3N lithium battery or equivalent. Pull control knobs out of sides of body, grasp on/off knob and gently pull circuit board out. To reinstall, insert circuit board into tube and insert knobs through sides of body into holes on potentiometers.

**Be careful of battery polarity. Inserting battery with polarity reversed will damage circuitry and void warranty.**

**Changing LED:** Remove circuit from body. Using needle-nose pliers or tweezers, remove LED from socket. Insert other color LED into socket, reinstall circuit board into body.

**5 Year limited warranty: Rigel Systems, 26850 Basswood Ave, Rancho Palos Verdes CA, 90275** warrants to the original consumer purchaser of its product that the product will be free of defects in material or workmanship 5 years from the date of purchase under normal use.

During this warranty period, **Rigel Systems** will, at its option, repair or replace the product without charge for parts or labor when delivered to **Rigel Systems** with proof of the date of purchase and a statement of the problem with the product. Shipping and handling charges to **Rigel Systems** are your responsibility.

This warranty does not apply if the product has been altered or repaired by anyone other than **Rigel Systems** or has been subjected to purchaser abuse, accident, negligence or damage subsequent to purchase including battery damage to product.

This warranty excludes incidental or consequential damages resulting from the product or use of the product. The product is not a toy. Keep away from children.

#### **How To Order Eyepiece Adaptor.**

Specify 10 mm or 14 mm screw-in or set-screw. Send **\$7.95** plus **\$2.00** shipping and handling (CA residents add 8.25% tax) to:

**Rigel Systems**  
**26850 Basswood Ave.**  
**Rancho Palos Verdes, CA 90275**